

Meter Location Guide

Click on a model number below to show meter location

C180
C235
C285
C360
C400
C450
C500
C550
C600
C650
CD1500
CD2000
cm4010
cm2510
cm2020
cm3120
cm3520
cm4520
cm2520
cm3521
cm2522
cm3522

cm4521
cm5520
cm6520
cm3530/1
cm4530/1

cx2100
DL200
DF200
DF260
DL260
DF270
DL270
DF360
DL360
DF370
DL370

DL250
DL355
DL450
DL600
DL460
DL550
DL650
DL850
fx2100
fx3000
fx2080
fx2081
sx1480
sx1481
im3510 (ZB35)
im4510 (ZB45)
im3511
im4511
im4512
im3512

im2020 (ZC20)
im2520 (ZC25)
im2520f (ZF25)
im3520 (ZC35)
im4720 (ZC47)
im5520 (ZC55)
im6020
im7520
im2330
im2830
im3530
im4530
im5530
im6030
im7230
im8530
im6530 (ZD65)
im8130 (ZD81)
im9220

VarioLink 3200x
VarioLink 3622
VarioLink 4222
VarioLink 5022
VarioLink 2821
VarioLink 2221
VarioLink 6522c
VarioLink 5522c
VarioLink 4522c
VarioLink 7522
VarioLink 6022
VarioLink 9522
VarioLink 3622c
VarioLink 2822c


Canon imageRUNNER Models
OceVPDP (110/120/135)

Model Name:

C360 DL250
C285 DL355
C235 DL450
C180 DL600

Meter Location:

Meter is located inside cover
on lower right corner of machine




Model Name:

- C400
- C450
- C500
- C550
- C600
- C650

Meter Location:

Meter is located on outer right side of machine below power switch




Model Name:

CD2000

CD1500

Meter Location:

Meters are located on right side
of machine below power switch
Record Upper & Lower counters



Model Name:

cm4520

cm3520

cm3120

cm2020

Meter Location:

Meters are located on right side
of machine

Record Upper & Lower counters




Model Name:


cm3530
cm4530
cm3531
cm4531

Meter Location:


Follow instructions to locate electronic counters on the control panel




Press the **USER FUNCTIONS** button on the control panel.



Touch the **TOTAL COUNTER** button.



Touch the **PRINT COUNTER** key.



The counter window is displayed. Record the numbers at the bottom of the **Black** and **Total** counters in the lower right corner of the screen.

Model Name:

DL200 DL270
DF200 DF360
DF260 DL360
DL260 DF370
DF270 DL370

Meter Location:

Meter is located on right side of control panel



Model Name:

im5520 (PCN: ZC55)

im4720 (PCN: ZC47)

DL550

DL460

Meter Location:

Meter is located on right side
of machine



Model Name:

DL650

Meter Location:

Meter is located inside cover
on upper left corner of machine



Model Name:

DL850

Meter Location:

Meter is located inside cover
on upper left corner of machine



Model Name:

im2020 (ZC20)


im2520 (ZC25)

im2520f (ZF25)

im3520 (ZC35)

Meter Location:

Meter is located inside cover
on lower right corner of machine



Model Name:

im4512

im3512

im4511


im3511

im4510 (PCN: ZB45)

im3510 (PCN: ZB35)

Meter Location:

Meter is located inside front cover
next to power switch




Model Name:

im6020

im7520

Meter Location:

Meter is located inside front cover
on upper left corner of machine



Model Name:

im8130 (PCN: ZD81)

im6530 (PCN: ZD65)

Meter Location:

Meter is located on left corner
of control panel




Model Name:

im9220

Meter Location:

Meter is located inside front cover on upper left corner of machine



Model Name:

fx2080


fx2081

sx1480

sx1481

Meter Location:

Meter is located on right side of machine, toward the back.




Model Name:

fx2100

fx3000

Meter Location:

- Press **Menu** on the control panel.
- Press **1** on the 10-key pad.
- Record the **Total** in the Page Counter window.




Model Name:

cm2520
cm3521

Meter Location:

Press **Utility/Counter** on the control panel. Record the **Total** and **Black** readings in the Meter Count window.




Model Name:

im2330 im5530
im2830 im6030
im3530 im7230
im4530 im8530

Meter Location:

Press **USER FUNCTIONS** on the control panel.
Press **TOTAL COUNTER** on the touch screen.
Press **PRINT COUNTER** on the touch screen.
Record the **TOTAL** readings in the lower right corner of the counter window.




Model Name:

cm4010

cm2510

Meter Location:

To display the “Total Count” screen, press and hold the “COPY” key on the control panel. Record the “Total” and “Black” counters.




Model Name:

cm2522 VarioLink 6522c
cm3522 VarioLink 5522c
cm4521 VarioLink 4522c
cm5520 VarioLink 3622c
cm6520 VarioLink 2822c

Meter Location:

- 1) Press **Utility/Counter** on the control panel
- 2) Touch **Meter Count**
- 3) Record the **Total** and **Black** readings




Model Name:

cx2100

Meter Location:

- Press **Menu** on the control panel.
- Press **8** then **2** on the 10-key pad.
- Record the **Total** in the Page Counter window.
- Press **OK** (While *Total* is highlighted)
- Record the **B&W** counter

< [Back to Index](#)



Canon


CANON SOLUTIONS AMERICA

Model Name:

VL3200x

Meter Location:

- Press **Menu** on the control panel.
- Press 8 then 2 on the 10-key pad.
- Record the **Total** in the Page Counter window.



Model Name:

VarioLink 3622

VarioLink 4222


VarioLink 5022

VarioLink 6022

VarioLink 7522

Meter Location:



- 1) Press **Utility/Counter** on the control panel
- 2) Touch **Meter Count**
- 3) Record the **Total** counter reading



Model Name:

VarioLink 2821

VarioLink 2221





Meter Location:

- 1) Press **Utility/Counter** on the control panel
- 2) Record the **Total Counter** reading

Model Name:

VarioLink 9522



< [Back to Index](#)

Canon

CANON SOLUTIONS AMERICA

Meter Location Guide - imageRUNNER Models

Click on a product type below to show meter location

[imageRUNNER Black & White Products](#)


[imageRUNNER Color Products](#)

Canon imageRUNNER Black & White Product

Meter Location:


Control Panel with Counter Check

- 1) Press **Counter Check** located on the right or left side of the control panel
- 2) Record the **101 Total 1** Counter



Control Panel with 123

- 1) Press **123** on the control panel
- 2) Record the **101 Total 1** Counter



Canon imageRUNNER ADVANCE Black & White Product Series

Meter Location:


Control Panel with Counter Check

- 1) Press Counter Check located on the right or left side of control panel
- 2) Record the **101 Total 1** Counter



Control Panel with 123

- 1) Press **123** on the control panel
- 2) Record the **101 Total 1** Counter



Canon imageRUNNER ADVANCE Color Product Series

Meter Location:


Control Panel with Counter Check

- 1) Press Counter Check on the control panel
- 2) Record the **101 Total 1** Counter
- 3) Record the **108 Total (Black1)** Counter




Control Panel with 123

- 1) Press **123** on the control panel
- 2) Record the **101 Total 1** Counter
- 3) Record the **108 Total (Black1)** Counter



Model Name:
OceVDP (110/120/135)



Meter Location:

- 1) Press System on the User Interface Screen**
- 2) Press Maintenance on the upper left section**
- 3) Record the Total Counter**